


Smartpack2 Touch Controller

Ports and Navigation



Smartpack2 Touch Controller

NOTE: To configure the system, you must be logged in as an administrator. Default credentials are:

User name: admin

Password: admin

To set up TCP/IP communication (in order to connect a computer to the controller via Ethernet or USB Wi-fi dongle:

1. Use the touch screen to navigate to: **System Conf. > Device Settings > Network Settings [TCP/IP Setup]**.
2. Choose the tab for the port to be used for the connection, and enter any required parameters.
 - **eth0** – Side Ethernet port. IP settings assigned automatically (DHCP), if your network supports this capability. Otherwise, obtain IP settings from your network administrator. Supports IPV4 and IPV6.
 - **eth1** – Front Ethernet port. Fixed IP address 10.10.0.1. Any device running a DHCP client, connected to this port, will be given an IP address. Supports IPV4.
 - **eth2** – USB port. Requires a USB Gigabit Ethernet adapter. IP settings assigned are automatically (DHCP), if your network supports this capability. Otherwise, obtain IP settings from your network administrator. Supports IPV4 and IPV6.
 - **wlan0** – USB port. For connecting (supported) Wi-Fi dongles. Fixed IP address 10.20.0.1. Any device running a DHCP client, connected to this port, will be given an IP address. Supports IPV4.
 - **wwan0** – Front USB port. For connecting a 4G USB cellular modem. Supports IPV4.



Home Page

The home page provides an overview of system status, and includes navigational links for controller configuration.



System Configuration

Use this section to interrogate the system, and to make changes or reprogram the system factory default parameters. Administrators can program basic system parameters, network configuration, system voltages, system calibrations, generator configuration, rectifier's configuration, solar chargers configuration, DC-DC converters configuration, battery configuration, battery test and battery boost configuration, symmetry configuration.



Alarm Configuration

Use this section to configure the system LVD devices and system alarm tables, to create/delete and to enable/disable alarms and alarm groups, enable/disable inputs and outputs of the system, program alarm parameters and severity levels for AC mains alarm, generator alarm, rectifiers alarm, solar chargers alarm, DC-DC converters alarm, load alarm, battery alarm, inputs/outputs alarm, and control system alarm.



Logs

This section is read-only. Use this section to view and save logs about events, data, energy, mains, generators, battery cycles, battery tests, battery run time, output run time, and DoD cycle count. To access the change log and accounts logs, you must be logged in as an administrator.



Commands

Use this section to execute commands to start and stop specific functions of the power system. Commands include resetting alarms, starting/stopping battery tests, starting/stopping battery boost, resetting system configuration, and executing relay tests; loading and saving configuration files are also performed in this category.



Logout/Login

Use this button to log in or log out of the controller. You must be logged in as administrator, in order to configure the controller.
